


PENDVR4GB Spy Pen Micro-Camera 4GB

User Manual

4GB mini Spy Pen Recorder DVR Video Camera



POWER BUTTON -

On - Hold this down until the blue light shows. This means the power is on.

Off - Hold down until the lights turns off

CAMERA -

Photo - To take a picture you will need to press the on/off button until the yellow light shows. This means it is ready to take and image. Press the on/off button once and the blue light will flash once this means it has captured an image.

Video - Hold the on/off button down until the yellow light disappears and is replaced with a blue one. If the blue light stays on it means it is recording so point the camera at the objects you wish to record. To stop the recording Press the on/off button again. What you have recorded will automatically save. The light should now be yellow which means it is in pause/camera mode.

USB CONNECTION - This is the 4GB USB flash drive, all photos and video's are stored on here.

MICROPHONE - This will record sound when the video mode is selected.